

# **POWERHORN™ Remote Siren, Model SH10A**

## **INSTALLATION AND OPERATING INSTRUCTIONS**

1. Set the Housecode dial on the SH10A to the same letter as your security system (DS7000, DC8700, etc).\*
2. If you want to control the SH10A from other types of X10 controllers, set the Unit Code dial on the SH10A to any unused number between 1 & 16.\*
3. Plug the SH10A into any unused AC outlet (not one that is controlled by a wall switch, in case the switch accidentally gets turned off).
4. To test the SH10A, trip your alarm system. The SH10A will sound for as long as the alarm in the security system console sounds, and then shut off a few seconds after you disarm the alarm.

### **WARNING:**

**The SH10A is extremely loud. To avoid permanent hearing damage, do not stand too close to it when you trip the alarm.**

5. To trip the SH10A from any X10 controller (if you hear a strange noise at night, for example): Press Unit Code-ON, then Unit Code-OFF, then Unit Code-ON, repeatedly. The SH10A will sound for as long as you keep pressing ON and OFF and will stop a few seconds after you stop pressing buttons. Or press Unit Code-ON and hold the button pressed for a few seconds. Or press All Lights On, then All Units Off, repeatedly.
6. You can use the SH10A as an annunciator: Press Unit Code-ON, on any X10 Controller and then press Dim or Bright. You will hear a ding or a dong for each button press.

\* Note: If you have a DC8700 security system it might be set to flash lights set to Unit Code 13. If that is the case set the SH10A to Unit Code 13.

**Check Out our Web site at:**

**[www.x10.com](http://www.x10.com)**

**For more information on X10 products and special promotional offers.**

### **X10 Wireless Technology, Inc. LIMITED 1-YEAR WARRANTY**

X10.com, a division of X10 Wireless Technology, Inc. (X10) warrants X10 products to be free from defective material and workmanship for a period of one (1) year from the original date of purchase at retail. X10 agrees to repair or replace, at its sole discretion, a defective X10 product if returned to X10 within the warranty period and with proof of purchase.

If service is required under this warranty:

1. Call 1-800-675-3044 or visit [www.x10.com](http://www.x10.com), or e-mail [sales@x10.com](mailto:sales@x10.com) to obtain a Return Merchandise Authorization (RMA) number.
2. Return the defective unit postage prepaid to X10 (see address on back).
3. Enclose a check for \$4.00 to cover postage and handling.
4. Enclose a dated proof of purchase.
5. X10 is not responsible for shipping damage. Units to be returned should be packed carefully.

**Please visit [www.x10.com/warranty](http://www.x10.com/warranty)**

**to complete your on-line warranty registration. Thank you.**

**For help or more information on setup, please visit: [www.x10.com/support](http://www.x10.com/support)**